



EN



Degree of difficulty

Instruction **TOILETRY BAG FOR HANGING**



1. Place Dekovil I Light on the wrong side of the outside, the coated side against the fabric. Cover with a damp cloth and iron in 6-second increments. Place fabric inlay on all remaining parts on the back side. Cover with a damp cloth and press the iron in 12-second increments, do not slide. Allow all pieces to cool flat for 30 minutes.



2. Folding bag A: Fold the cut piece longitudinally with the wrong sides facing, to make a rectangle of 11 cm in height. On bag A mark the position of the button loops on the folded edge 14 cm from both sides towards the middle. Fold button loops using 2 6 cm long braid ribbons (undo braids). Fix in place along the edge, under the markings, with 2 cm of extra protruding using double seams. Crimp the fabric layers along the side edges on the seam allowance. For the side folds fold 7.5 cm to the back and iron the fold. Fold the fabric edges back outwards, so that there is a 1.5 cm wide seam allowance protruding at the edges. Iron again. Pin the folds together.



3. Insert pocket B: Fold the cut piece with wrong sides facing to make a rectangle of 11 cm in height. Iron the fold. Tack the fabric layers together on the seam allowance along the outer edges. Mark a vertical centre line for subdivision.



4. Folding bag C: Fold the cut piece longitudinally with wrong sides facing, to make a rectangle of 13 cm in height. Pin the braid along the upper fold. Measure 14 cm from the edge for the button loops, mark and mark also 2 cm towards the middle. These 2 cm are left free when stitching the border as a button loop. Stitch up the border to the upper edge. Tack the fabric layers along the lateral edges of the seam allowance. Do the same for the side folds as described in Step 2.



5. Zipper pocket D: Fold both pieces of fabric in half with wrong sides facing, this results in a height of 10.5 cm (including 1.5 cm seam allowance at the bottom edge) or 5 cm (without seam allowance). Iron in the folds. Slide the folds towards the zipper teeth to make them visible = 1 cm wide. Pin the folded edges to the zipper tape. Stitch the zipper on both sides. Iron the bag. Tack or stitch the fabric edges together with the outer edges.



6. For the wrap on the outside of the bag, mark the centre line 35 cm vertically (light grey stripe on the pattern). Cut off 80 cm from the corded ribbon. Lay 45 cm of the end of the corded ribbon to form the loop and pin the last 5 cm together. Slide 2 half rings on the end of the second ribbon, fold ribbon back to 5 cm and pin. Stitch across 1 cm from the half rings. Now pin the corded ribbon along the centre mark on the outside pocket. Thread the Cotton 30 multicolour. Choose a narrow decorative stitch or close zigzag stitch. Stitch the corded ribbon close to the edge on both sides with the decorative stitch or zigzag.



7. Place the bag A on the cream-coloured internal side as per the pattern. Stitch along the side edges on the seam allowance with basting stitches. Cover the cut edges of bag A with the corded ribbon. Stitch on both sides with the decorative stitch and Cotton 30 multicolour including the lateral folds. Next, stitch the central vertical subdivision of the pocket B along the mark. Now cover the cut edges of the bag B with the corded ribbon. Stitch with decorative stitching and Cotton 30 multicolour along the edges.



8. Place bag C under bag B and the zipper pocket next to that. Cover the cut edges of both bags in the middle with the corded ribbon. Stitch on both sides with the decorative stitch and Cotton 30 multicolour and fix the sides of bag C in place.



9. Place the external side with right sides facing on the inside and pin. Make sure you do not catch the corded ribbon loop on the outside in the stitching. It is best to fix the loop in place with pins. Stitch the 1.5 cm seam all the way around, leaving a slit of approx. 18 cm along the lower edge for turning. For the folding bags A and C, take care that the folds are not caught in the side seam. Trim the seam allowances back and clip them at the corners. Turn through the slit. Form and iron the edges. Fold the seam allowances at the slot inwards and close the slit with hand stitches. Sew on the buttons.

Gütermann GmbH

Landstr. 1

DE- 79261 Gutach-Breisgau

Tel +49 76 81 21-0

Fax +49 76 81 21-449

contact@guetermann.com