



EN



Instruction **SHOULDER BAG**



1. Place the Decovil-I lining on the backs of the patterned outer fabric and the faux leather and press on in 15-second steps. Place volume fleece on the lining cut pieces and also press over the entire area in 15-second steps. Allow the pieces to cool flat.



2. Fold the closing flaps crosswise over each other and iron the break using an ironing cloth. Place the fabric lining up to the break on the left side of the faux leather, place on the Vliesofix section away from the break. Cover with baking paper and iron to fix. Peel off the baking paper. Do the same for the second flap. Fix one half of the magnetic closure in the centre with a distance of 2 cm from the iron break on the half reinforced with fabric lining. Now fold the flaps again in the break and iron on top of an ironing cloth, the Vliesofix joins both sides. Stitch away from the break with Deco Stitch 70 (with bottom thread in Sew-all Thread in the same colour) with 2-3 mm to the outer edges in triple decorative stitch, stitch length 3.5 mm. Pull the starting threads to the back and tie a knot.



3. Place Vliesofix between two left on left handle fastenings, iron using an ironing cloth. Work along the edges with decorative stitches as on the flap. Apply Vliesofix on the back of the strap fastening, cover with baking paper and iron. Peel off the baking paper. Slide the snap hook half way up to the belt fastening and fold the strips flush on to each other. Between the strips, slide the end of the strap up to 0.5 cm in front of the snap hook. Place an ironing cloth and iron the belt fastening, the Vliesofix joins the layers to each other. To fix the strap, stitch a 3 cm square with 3 mm distance to the outer edges with a triple decorative stitch. Punch in one rivet over each corner of the square.



4. Melt the second transverse edge of the strap with a lighter. When it is no longer too hot, gently squeeze the fibres together. Place this end of the strap around the bar of the strap buckle from the back to the front, move to the back again. Slide on the eyelet of the second snap hook. Then return the end of the strap to the strap buckle, making sure that the strap lies flat and does not twist. Thread it from the back to the front over the strap bar and guide it back again. It helps to pull the strap threaded in first away from the bar, so that the second layer can slide better behind it. Fold the strap end as a 4 cm long loop after the bar. Stitch in place with a double lockstitch seam.



5. Place the outer sides of faux leather and flower bud pattern right on right, fix the lower edge and the vertical edges with fabric clips on top of each other (do not use needles, as this will create holes in the faux leather). Stitch the seams. Iron the seam allowances apart. Fold the side seam away from one corner congruently onto the bottom seam to create a triangle at the top. Measure 6 cm on the seam line away from the top. At this point, mark a line at right angles to both sides. Stitch the bottom corner along the marking. Cut back the corners up to seam allowance width, cut in the seam allowances towards the ends. Iron the seam allowances apart. Do the same for the second bottom corner.



6. Iron the seam allowances of the side bottom seams together to the side. Place the pelmet interlining on the left side of the bottom, the bottom reaches precisely from corner to corner. If the dimensions are slightly different, correct before ironing. Fix the reinforcement with an ironing cloth by pressing on in 15-second increments. Then leave to cool down well. Turn the outer bag. Fix the base nails 2.5 cm from the corners in accordance with the manufacturer's specifications and using the tools provided in the bottom from the right bag side.



7. Place the inner lining sides fixed with volume fleece right on right. Stitch the side and bottom edges, making sure that there is an approx. 15 cm long slit left for turning in the middle. Iron the seam allowances apart. Work the bottom corners as described in step 5.



8. Position the closing flaps centrally and exactly opposite each other on the upper edges of the outer sides of the bag and fix with clips. The magnetic closure halves face the outer side of the bag, the cut edges are flush with the cut edges of the bag. On the two handle fastenings, push on one half ring each and fold crosswise in half. Secure both fastenings in the middle over the side seams of the bag. Here too, the cut edges close flush with those of the bag. Slide the bag lining right on right over outer fabric bag, the seams are placed exactly on top of each other. Fix the layers together. Along the top edge, stitch all around the seam, including the flaps and handle fastenings. Iron the seam allowances directed into the lining.



9. Turn the bag through the slot in the lining. Fold the closing flaps away from the seam onto the lining and, leaving 0.8 cm from the seam, stitch on the lining and the seam allowance underneath. Then slide the lining into bag and iron the top edge. Place the open slit edges on top of each other and stitch together with a narrow edge. Alternatively, close the slit edges with hand stitches.



Gütermann GmbH

Landstr. 1

DE- 79261 Gutach-Breisgau

Tel +49 7681 21-0

Fax +49 7681 21-449

contact@guetermann.com